



# Product Information

## Webcrete™ 95 Fast-Setting Latex-Fortified Portland Cement Patch

### **Product Description:**

DURABOND® Webcrete™ 95 is a fast-setting latex-fortified Portland cement patch for interior use. This product may be used to skim coat or featheredge up to 1/2" deep in one application. Floor covering can be installed after just one hour from application. Webcrete 95 is extremely flexible and resilient for use to patch and smooth floors prior to the installation of ceramic tile, carpet, resilient and wood flooring. When mixed with DURABOND D-LI6 High Strength Additive instead of water, not only is the performance and flexibility improved, but the Webcrete 95 can also be used as an embossing leveler.

### **Product Benefits:**

- Excellent for skim coating, patching, and leveling
- Low installed cost
- High strength
- Walk on after 30 minutes

### **Performance Characteristics:**

- Latex fortified
- Ability to featheredge
- Water resistant
- No need for post sanding or grinding
- No shrinkage
- Crack resistant
- Compatible with all DURABOND flooring adhesives
- Up to 1/2" depth in one application

### **Suitable Substrates:**

- Properly prepared concrete
- Cementitious backer board
- Structurally sound exterior grade plywood (interior/dry use only)
- Existing, well bonded vinyl/VCT or ceramic tile
- Cutback adhesive residue (dry only)

### **TYPICAL PHYSICAL PROPERTIES**

Working Time:	5-15 minutes
Pot Life:	10-15 minutes
Final Set:	25-35 minutes
Cure Time:	Final cure is 28 days*

\*Do not allow traffic over floor for 1 hour from installation.

### **Surface Preparation:**

Surfaces must be structurally sound, clean and free of dust, dirt, paint, soap film, adhesive residue, grease, curing compounds and other foreign material that could inhibit bonding. For best results, material and surface should be above 45°F.

### **Mixing Instructions:**

Add 25 lbs. of Webcrete 95 to 3 3/4 quarts of clean, cool, potable water or DURABOND D-LI6 High Strength Additive. Use 3/4 quarts of liquid for 5 lbs. of Webcrete 95 or 6 quarts to 40 lbs. of Webcrete 95. DO NOT OVER WATER. Do not mix more material than can be used in 10 to 15 minutes. The material may be re-mixed; do not re-temper by adding more liquid. The pot life of the material is dramatically affected by jobsite conditions, the powder/liquid mix ratio, and temperature of the jobsite and materials; cold materials, substrate, jobsite, and mixing water will extend the pot life.

### **Coverage (ft.<sup>2</sup>)\*:**

Thickness	5 Lbs.	25 Lbs.	40 Lbs.
1/8"	5-7	25-35	40-56
Skim Coat	125-150	625-750	1000-1200
Emboss Leveler	250-300	1250-1500	1000-4000

\*Coverage rates are approximate and actual coverage will vary based on application technique, waste, and/or other jobsite conditions.

### **Application:**

With the flat side of a trowel held at a 45° angle, work patch into surface filling all broken areas, depressions and cracks in the substrate. "Key in" but do not over trowel.

#### Application over plywood:

Please refer to the proper flooring industry and APA standards for plywood subfloor installation and preparation. Clean and rough-sand the plywood. Due to the limitations of plywood as a substrate, it is not intended for use in exterior, wet interior, or applications subject to heavy/commercial traffic.

#### Application over existing vinyl/VCT flooring and cutback: (dry only)

Vinyl/VCT must be clean and well bonded to the substrate. Remove any loose pieces of vinyl/VCT flooring or cutback adhesive residue. Roughen new surfaces or flooring with urethane wear layers. Do not apply over cushion back or perimeter bonded sheet vinyl.

#### Application over existing ceramic tile:

Ensure that the ceramic tile is clean and well bonded to the substrate. Mechanical abrasion with a Carborundum disk is required, followed by a clean water wash. The installation must be thoroughly rinsed and dry prior to applying the Webcrete 95.

#### Application as an emboss leveler:

Webcrete 95 must be mixed with DURABOND D-LI6 High Strength Additive when used as an emboss fill/leveler. Vinyl/VCT must be clean and well bonded to the substrate. Remove any loose pieces of vinyl/VCT flooring. Roughen new or smooth surfaces, or flooring with urethane wear layers.

Warning: DO NOT SAND ASBESTOS FLOORS! The installation must be thoroughly rinsed and dried. Use the flat side of a trowel held at a 45° angle to spread a thin layer of Webcrete 95 over the embossed floor covering. Avoid thick or heavy applications.

An embossing leveler need only be thick enough to fill in the depressions of the floor covering. Make sure coverage is smooth and uniform; avoid over-troweling. A second application may be required on deeply embossed floors.

### **LIMITED WARRANTY**

All statements, technical information and recommendations set forth herein are based on tests which Bostik Findley believes to be reliable. However, Bostik Findley does not guarantee their accuracy or completeness. The buyer should conduct its own tests of this product before use to determine proper preparation technique and suitability for proposed application. Any sale of this product shall be on terms and conditions set forth on Bostik Findley's order acknowledgement. Bostik Findley warrants that the product conforms with Bostik Findley's written specifications, and is free from defects. BOSTIK FINDLEY DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE BUYER'S SOLE REMEDY FOR NONCOMPLIANCE WITH THIS WARRANTY SHALL BE FOR THE REPLACEMENT OF THE PRODUCT OR REFUND OF THE BUYER'S PURCHASE PRICE. IN NO CASE WILL BOSTIK FINDLEY BE LIABLE FOR DIRECT, CONSEQUENTIAL, ECONOMIC OR OTHER DAMAGES.

### **Limitations:**

- The use of solvent-based sheet flooring adhesive over Webcrete™ 95 is not recommended; please refer to the applicable DURABOND solvent-free adhesive.
- For areas larger than 4 ft<sup>2</sup> with a consistent 1/2" depression, the use of a DURABOND self-leveling underlayment product is recommended.
- This product is not designed as a wear surface; an appropriate floor covering must be installed before it is open to normal traffic.
- Cutback adhesive must be fully removed prior to installing solid wood flooring.

### **Clean Up, Storage, and Shelf Life:**

Wash tools immediately with water. Close container tightly and store unused powder in a cool, dry place. Product has a one-year shelf life.

### **Packaging:**

DURABOND Webcrete 95 is available in 25lb. bags and 5 lb. bags (6/case). For the name of the distributor nearest you contact Customer Service at 1-888-592-8558.



### **PLANT LOCATIONS**

CONYERS, GA 30207  
TEMECULA, CA 92590  
PAULSBORO, NJ 08066  
TWINSBURG, OH 44087

[www.bostikfindley-us.com](http://www.bostikfindley-us.com)

September 2001; Supersedes all previously published literature.